


























Shortcut-key for the design software Pipe-IQ for FAAST Aspiration Smoke Detectors

Function Pipe-IQ	Symbol	Use
Select all entities		Ctrl + A
Cut		Ctrl + X
Copy		Ctrl + C
Paste		Ctrl + V
Delete selected entity		Del
Delete all entities		Shift + Del
Move entire network		Shift + Drag
Select entity including child		Caps Lock ON
Select a single entity		Caps Lock OFF
Pan design area		Ctrl + P
Deselect pan mode		Double-click in the design area
Total pipe length		Ctrl + A
Add vertical pipe		Ctrl + Up arrow
Add horizontal pipe		Ctrl + Down arrow
Add left slant pipe		Ctrl + Left arrow
Add right slant pipe		Ctrl + Right arrow
Connect pipes		Ctrl + D
Top view		Ctrl + T
Front view		Ctrl + F
Right view		Ctrl + R
Isometric view		Ctrl + I
Zoom out		Ctrl + -
Zoom in		Ctrl + +
Zoom fit		Ctrl + ENTER
Disconnect pipe		Ctrl + drag
Flip		Ctrl + M
Rotate left		Ctrl + [
Rotate right		Ctrl +]
Undo		Ctrl + Z
Redo		Ctrl + Y
Enable draw pipe		Double-click in the design area
Show quick edit		Ctrl + W
Edit properties		Ctrl + E

Further information: www.faastr-detection.com

Edition: 07/2017

Pipe-IQ reference: version 2.8.5